


S2335

Exhibit 15.9

29.15


Schedule 29.2 - Interpretive Diagrams

29.15.1 Diagram 1 - B85 and B99 design vehicle dimensions



DIMENSIONS IN MILLIMETRES


B85 (85TH PERCENTILE) CAR



DIMENSIONS IN MILLIMETRES

B99 (99.8TH PERCENTILE) VEHICLE

29.15.4 Diagram 4 – Vehicle Swept Path Design




LEGEND:

- = Denotes the B85 base dimension swept path
- - - = Denotes the B85 design template which includes 2 x 300 mm manoeuvring clearances only

NOTE: This is the minimum radius turn for a B85 vehicle.

**Example of the B85 Design Template
5.8m Radius Turn**




Turn radius—8.0 m
Scale 1:200

LEGEND:

- = Denotes the B85 base dimension swept path
- = Denotes the B85 design template which includes 2 x 300 mm manoeuvring clearances only

**Example of the B85 Design Template
8.0m Radius Turn**




LEGEND:

- = Denotes the B99 base dimension swept path
- - - = Denotes the B99 design template which includes manoeuvring and circulation clearances, 300 mm on the inside and 600 mm on the outside

NOTE: This is the minimum radius turn for a B99 vehicle.

Example of the B99 Design Template

6.3m Radius Turn



LEGEND:

- = Denotes the B99 base dimension swept path
- - - = Denotes the B99 design template which includes maneuvering and circulation clearances, 300 mm on the inside and 600 mm on the outside

Example of the B99 Design Template

8.0m Radius Turn